




Pressure drop table for double seat valve B925 DN25




Pressure drop table for double seat valve B925 DN40




Pressure drop table for double seat valve B925 DN50




Pressure drop table for double seat valve B925 DN2"1/2 (DN63.5)




Pressure drop table for double seat valve B925 DN65



Pressure drop table for double seat valve B925 DN3'' (DN76.1)



Pressure drop table for double seat valve B925 DN80



Pressure drop table for double seat valve B925 DN4'' (DN101.6)

